

■ **NOTES:**

REVIEW ALL LOCAL BUILDING CODE REQUIREMENTS PRIOR TO INSTALLATION AND PRACTICE PROPER SAFETY STANDARDS.

WHEN USING WITH RAILWAYS TRADITIONAL AND SIGNATURE RAILING, USE THE #14x1-1/4" SCREWS (PROVIDED) WHEN ATTACHING BOTTOM RAIL BRACKETS.

■ **Structural Post Mount Installation**

GAF-Elk offers a structural post mount for the installation of RailWays Traditional and Signature railing systems and post sleeves directly to a solid surface. Structural Posts are available in both 36" and 42" heights.

The post mount may either be attached to concrete or wood surfaces. Once having determined the type of application, additional fastening hardware must be purchased separately. For concrete applications, 3/8" X 3" concrete anchor bolts are required. For wood substructure applications, a wood mounting kit is required, which includes 3/8" X 4-1/2" (hot dipped galvanized) through bolts. If leveling is required, shim where necessary with galvanized washers (washers sold separately).

Attachment of the post mount is accomplished by using the base plate as a template to locate and drill the necessary attachment holes for either application. Follow suggested hardware manufacturer's normal installation instructions.

For wood substructure applications, the post mount MUST be installed as shown in figures 3 & 4. NOTE: If using the structural post mount for a wood application, you MUST install blocking as shown in Fig. 3.

